

NOTES:

- 1. EMBEDMENT LENGTHS SHALL BE AS SHOWN ON APPROPRIATE 800 SERIES PLATES.
- 2. REFER TO APPROPRIATE 800 SERIES STANDARD PLATE REGARDING ANCHOR BASE DATA.
- 3. ALL ANCHOR BOLTS SHALL BE PLUMB AFTER FOUNDATION INSTALLATION. STEEL TEMPLATE PLATE SHALL BE USED TO SET ANCHOR BOLTS.
- 4. BASE PLATE SHALL BE IN FULL CONTACT WITH ALL FLAT WASHERS.
- 5. ALL ANCHOR BOLTS SHALL BE TIGHTENED USING TURN OF NUT METHOD. (30° min to 45° max turn after snug tight)
- 6. GROUT SHALL NOT BE PLACED BETWEEN THE BASE PLATE AND CONCRETE BASE.

